



ボールコック ハンドル開閉位置 (コック共通)


A-1




A-2




B-1




B-2




C-1




C-2




D-1




D-2




E-1




E-2




F-1




F-2




G-1



G-2



H-1



H-2

